

# SERVICE INDICATOR & WARNING LIGHTS

1991 Mazda Miata


1990-92 MAINTENANCE  
Mazda Service Indicator & Warning Lights

Miata

## SERVICE INDICATOR & WARNING LIGHTS

The warning lights will come on with the ignition. Any warning light which does not come with the ignition must be checked and repaired.

1. Fuel Gauge
2. Tachometer
3. Engine Oil Pressure Gauge
4. Turn Signal Indicator Lights
5. Odometer
6. Speedometer
7. Engine Temperature Gauge
8. AIR BAG System Warning Light
9. Headlight Retractor Indicator Light
10. CHARGE System Warning Light
11. CHECK (Malfunction) Indicator Light
12. Seat Belt Warning Light
13. BRAKE Warning Light
14. Headlight High Beam Indicator Light
15. Trip Odometer
16. Trip Odometer Reset Button
17. O/D (Overdrive) OFF Indicator
18. ANTI-LOCK Brake System Warning Light
19. Rear Window Defroster Indicator Light
20. Low Washer Fluid Level Warning Light



90H05044

Fig. 1: Dash Gauges & Warning Lights  
Courtesy of Mazda Motor of America, Inc.

### "BRAKE" SYSTEM WARNING LIGHT

Light comes on with parking brake. Low brake fluid is indicated if light remains on when parking brake off.

### SEAT BELT WARNING LIGHT

Light and beeper will go on for about 6 seconds or until driver's belt is locked, when ignition is turned on.

### CHARGE SYSTEM WARNING LIGHT

Light indicates a malfunction of either the alternator or the electrical wiring system.

### MALFUNCTION INDICATOR LIGHT

Light warns of a problem in the engine electronic control and sensor circuits.

### SUPPLEMENTAL RESTRAINT SYSTEM WARNING LIGHT

Light shows a system malfunction by flashing, glowing continuously or not glowing at all.

### ANTI-LOCK BRAKE SYSTEM (ABS) WARNING LIGHT

Light comes on when the ignition switch is ON and should go off after the engine is started. The ABS warning light will remain on if there is a malfunction in the anti-lock brake system.

#### **HEADLIGHT HIGH BEAM INDICATOR**

Indicates headlight high beam is on or turn signal lever is in flash-to-pass position.

#### **HEADLIGHT RETRACTOR INDICATOR**

Comes on while headlights are retracting or extending. If indicator remains on check and repair headlight retractor.